

HOW TO SET UP


RETRACTABLE BANNER STAND

1 OPEN THE FEET



Rotate both stabilizing feet 90°.

2 ASSEMBLE THE POLE



Join all three pole sections securely.

3 INSERT THE POLE



Insert the bottom of the pole fully into the base socket.

4 RAISE THE BANNER



From behind the stand, slowly pull the banner upward by the top rail.

5 SECURE THE TOP RAIL



Attach the top rail securely to the pole's top hook.

6 READY TO DISPLAY



Check that the banner is upright and the feet are fully open.

PACKING AWAY



Hold the top rail, release it from the pole, and slowly guide the banner into the base. Keep it centred to prevent rubbing against the edges. Never let it snap back. Remove and fold the pole, then rotate the feet inward.